



The information and data contained herein are believed to be accurate and reliable. This information does not constitute a warranty and should be used in conjunction with the project specification document supplied by Allco Waterproofing Solutions Ltd Please contact Allco Waterproofing Solutions Ltd with any questions or deviations from this information. © Allco Waterproofing Solution Ltd For Technical Advice Contact: Web: www.allco.co.nz Email: info@allco.co.nz Telephone: 09 448 1185 Facsimile: 09 448 1186



VOLTEX LAPS FROM BEAM FORMWORK. PLACED BACK OVER TOP OF BEAM WITH 150MM LAP

VOLTEX BANDAGE TO BEAM / LIFT SLAB JUNCTION

VOLTEX BONDED TO LIFT SLAB

VOLTEX BONDED TO BEAM. LAID IN BEAM FORMORK. NOTE - MEMBRANE COULD BE APPLIED AFTER CASTING BEAM AND LAPPED BACK TO LIFT SLAB