


HYDROTECH MM6125  
MEMBRANE SYSTEM



DRAIN / OUTLET


HYDROTECH FLEX-FLASH UN  
LAPS IN DRAIN CLAMP AREA

HYDROTECH FLEX-FLASH F  
LAPPED OVER UN


NOTE

HYDROTECH MUST BE LAID  
WITH A PROTECTION LAYER  
OVER THE MM6125.  
HYDROFLEX 30 or CASALI  
OLYMPIA or CASALI CAP SHEET

HYDROTECH MM6125  
MEMBRANE SYSTEM



OVERFLOW  
INSERT



OVERFLOW

HYDROTECH FLEX-FLASH UN  
LAPS IN DRAIN CLAMP AREA

HYDROTECH FLEX-FLASH F  
LAPPED OVER UN

HYDROTECH MM6125  
MEMBRANE SYSTEM

PROTECTION SHEET

1ST LAYER.

2ND LAYER.

FLEX-FLASH F

CONCRETE  
SUBSTRATE

1

HYDROTECH - OUTLET / OVERFLOW

SCALE: NTS



The information and data contained herein are believed to be accurate and reliable.  
This information does not constitute a warranty and should be used in conjunction with  
the project specification document supplied by Allco Waterproofing Solutions Ltd  
Please contact Allco Waterproofing Solutions Ltd with any questions or deviations from  
this information.  
© Allco Waterproofing Solution Ltd

For Technical Advice Contact:  
Web: [www.allco.co.nz](http://www.allco.co.nz)  
Email: [info@allco.co.nz](mailto:info@allco.co.nz)  
Telephone: 09 448 1185  
Facsimile: 09 448 1186



DRAWN BY:  
ALLCO

DATE:  
06/19

DRAWING REF:  
H-011

VER:  
1.0