


STEP 3.  
CASALI Base Sheet Layer  
Install Double on the vertical plane with a  
min. 80mm lap onto base sheet and over  
onto the opposite corner

STEP 4.  
CASALI Base Sheet Layer  
Install 2nd Double from the opposite direction  
also with a min. 80mm lap onto base sheet.  
Mitre to corner over 1st Double




1

## INTERNAL CORNER - BASE SHEET

SCALE: NTS

STEP 3.  
CASALI Cap Sheet Layer.  
Install Double from the opposite direction also  
with a min. 80mm lap onto Main Feild-sheet.  
Mitre Butt join to 1st Double at bottom.

STEP 2.  
CASALI Cap Sheet layer.  
Install Double on the vertical plane with a  
min. 80mm lap onto the Main Feild-sheet  
and over onto the opposite corner



**\*Important Note:**  
Cap sheet Internal corner tabs must be  
installed in the opposite direction to the  
1st layer \*Base sheet

2

## INTERNAL CORNER - CAP SHEET

SCALE: NTS



The information and data contained herein are believed to be accurate and reliable.  
This information does not constitute a warranty and should be used in conjunction with  
the project specification document supplied by Allco Waterproofing Solutions Ltd  
Please contact Allco Waterproofing Solutions Ltd with any questions or deviations from  
this information.  
© Allco Waterproofing Solution Ltd

For Technical Advice Contact:  
Web: [www.allco.co.nz](http://www.allco.co.nz)  
Email: [info@allco.co.nz](mailto:info@allco.co.nz)  
Telephone: 09 448 1185  
Facsimile: 09 448 1186



DRAWN BY:  
ALLCO

DATE:  
06/19

DRAWING REF:  
CA-052

REV:  
1