

STEP 3.
CASALI Base Sheet Layer
Install Double on the vertical plane
with a min. 80mm lap onto base sheet
and over onto the opposite corner

STEP 4.
CASALI Base Sheet Layer
Install 2nd Double from the
opposite direction also with
a min. 80mm lap onto base sheet.
Mitre to corner over 1st Double

STEP 1.
Lay CASALI Torch-on
Base sheet to fillets

STEP 2. Base Sheet Layer
Install 140mm Gusset

NOTE:
Particular care should be taken to ensure
Overlaps do not leave holes or cuts exposed.

1


EXTERNAL CORNER - BASE SHEET

SCALE: NTS

NOTE:
Particular care should be taken to ensure
Overlaps do not leave holes or cuts exposed.

STEP 3.
CASALI Cap Sheet Layer.
Install Double from the opposite direction also
with a min. 80mm lap onto Main Field sheet.
Mitre Butt join to 1st Double at bottom.

*Important Note:
Cap sheet external corner tabs must be
installed in the opposite direction to the
1st layer Base sheet



STEP 2.
CASALI Cap Sheet layer.
Install Double on the vertical plane
with a min. 80mm lap onto the
Main Field-sheet and over
onto the opposite corner

STEP 1.
Lay CASALI Torch-on
Cap sheet to fillets

2

EXTERNAL CORNER - CAP SHEET

SCALE: NTS



The information and data contained herein are believed to be accurate and reliable.
This information does not constitute a warranty and should be used in conjunction with
the project specification document supplied by Allco Waterproofing Solutions Ltd
Please contact Allco Waterproofing Solutions Ltd with any questions or deviations from
this information.
© Allco Waterproofing Solution Ltd

For Technical Advice Contact:
Web: www.allco.co.nz
Email: info@allco.co.nz
Telephone: 09 448 1185
Facsimile: 09 448 1186



DRAWN BY:
ALLCO

DATE:
17/04/19

DRAWING REF:
CA-051

REV:
1